

**Remote Codes**

[Television](#)   [VCR](#)   [Stereo Amplifier](#)   [DVD](#)   [Combo](#)

**Remote TV Codes**

BRAND	CATEGORY	CODE
A Mark	Televisions	670
Action	Televisions	662
Admiral	Televisions	<b>720, 628, 522</b> , 514, 521, 605, 668, 669, 675
Advent	Televisions	<b>566</b>
Aiko	Televisions	727
Aiwa	Televisions	751
Akai	Televisions	<b>516</b> , 570, 573, 659, 660
Alba	Televisions	613
A-Mark	Televisions	620
Amtron	Televisions	657
Anam National	Televisions	509, 541, 620, 651, 657, 661, 663, 698
AOC	Televisions	505, 506, 519, 520, 573, 620, 627, 652, 653, 654, 659, 664, 665, 670, 672
Apex	Televisions	<b>595, 618, 743, 744</b> , 005, 006, 019, 020, 120, 745, 757
Archer	Televisions	620
Audiovox	Televisions	620, 657, 662, 672
Bell & Howell	Televisions	590, 669, 675
Broksonic	Televisions	<b>720, 752, 748, 656</b> , 562, 659, 661, 721
Capehart	Televisions	519, 627
Citizen	Televisions	506, 516, 523, 524, 525, 526, 590, 652, 654, 657, 658, 680, 727
Classic	Televisions	659
Colortyme	Televisions	573, 627, 652, 654, 660, 667, 668, 671, 674, 679, 681
Contec/Cony	Televisions	541, 655, 657, 661, 662, 726
Craig	Televisions	<b>541</b> , 536, 657, 661, 662, 666, 667, 694
Crosley	Televisions	<b>566</b>
Crown	Televisions	526, 536, 657, 666, 670
Curtis Mathes	Televisions	<b>516, 506, 703, 712</b> , 526, 573, 590, 641, 645, 650, 652, 654, 658, 659, 660, 664, 665, 667, 668, 670, 674, 680, 708
Daewoo	Televisions	<b>719</b> , 505, 524, 526, 529, 530, 531, 573, 652, 653, 654, 658, 659, 663, 664, 665, 670, 672, 674, 684, 698, 727
Daytron	Televisions	526, 627, 652, 654, 658, 665, 670, 672
Dimensia	Televisions	645, 650
Disney	Televisions	632
Dixi	Televisions	566, 620
Durabrand	Televisions	<b>623</b> 220, 221
Dumont	Televisions	501, 627, 652
Echostar	Televisions	742, 722
Electrohome	Televisions	526, 573, 651, 652, 654, 656, 659, 660, 665, 670, 709, 728
Elta	Televisions	532
Emerson	Televisions	<b>541, 544, 632, 537</b> , 526, 534, 535, 536, 538, 539, 573, 590, 627, 636, 642, 648, 652, 654, 655, 657, 658, 659, 660, 661, 662, 665, 666, 667, 669, 670, 677, 679, 682, 692, 696, 699, 720
Envision	Televisions	506, 573, 652, 654, 660, 664
Fisher	Televisions	<b>590</b> , 542, 683
Fujitsu	Televisions	534, 682, 694
Funai	Televisions	<b>694</b> , 534, 541, 569, 657, 661, 662, 677, 682
Gateway	Televisions	<b>746</b>
General Electric (GE)	Televisions	<b>503, 543, 784</b> , 508, 509, 544, 630, 645, 646, 650, 651, 652, 654, 659, 661, 663, 665, 667, 668, 670, 673, 676, 681, 690, 691, 698, 701, 715, 716, 725, 728, 742
Goldstar	Televisions	<b>505</b> , 523, 526, 545, 546, 566, 573, 652, 653, 654, 655, 656, 658, 659, 660, 664, 665, 670, 671, 678, 693, 730, 747
Go Video	Televisions	<b>692, 693</b>
Gradiente	Televisions	660, 671
Granada	Televisions	627, 670, 671
Grundig	Televisions	670, 673

Hallmark	Televisions	627, 652, 654, 659
Harmon Kardon	Televisions	561, 659
Hinari	Televisions	534
Hisense	Televisions	759
Hitachi	Televisions	<b>552, 523, 551, 605</b> , 526, 548, 549, 553, 554, 555, 585, 597, 626, 636, 638, 643, 648, 652, 654, 655, 665, 668, 669, 670, 672, 673, 702, 718, 726
iLo	Televisions	569, 720
Infinity	Televisions	566, 671
Insignia	Televisions	720
JBL	Televisions	566, 671
JC Penney	Televisions	<b>505, 516</b> , 506, 525, 526, 543, 546, 631, 645, 646, 650, 652, 653, 654, 658, 659, 664, 667, 668, 670, 673, 676, 678, 680, 690, 691, 701, 725, 726, 728, 730
Jensen	Televisions	556, 573, 652, 654, 660
JVC	Televisions	<b>557, 558, 642, 559</b> , 508, 649, 655, 667, 673, 676, 726, 735, 736, 737
Kawasho	Televisions	548, 561, 573, 652, 654, 664
Kenwood	Televisions	506, 573, 652, 654, 656, 659, 660, 664, 679, 681
Kloss Nova-beam	Televisions	657, 663, 698, 723, 724, 773
Klonka	Televisions	753
Konka	Televisions	<b>753</b>
KTV	Televisions	526, 539, 541, 573, 657, 658, 661, 662, 664, 665, 670, 696
LG	Televisions	<b>512, 678, 520</b>
Lloyds	Televisions	627, 679
Loewe	Televisions	566
Logik	Televisions	675
Luxman	Televisions	523, 652, 654
LXI	Televisions	<b>625, 590, 595, 503</b> , 563, 566, 617, 631, 635, 645, 646, 650, 654, 659, 667, 668, 678, 683, 691, 701, 725
Magnasonic	Televisions	573, 659, 660, 669, 672, 677
Magnavox	Televisions	<b>566, 506, 520</b> , 525, 536, 567, 568, 573, 610, 652, 654, 656, 659, 660, 664, 665, 666, 669, 671, 673, 674, 677, 723, 724, 729, 762
Majestic	Televisions	675
Marantz	Televisions	506, 566, 573, 652, 654, 660, 664, 665, 671, 678, 681
Megatron	Televisions	627, 654
Memorex	Televisions	<b>720, 521, 503</b> , 590, 627, 653, 654, 659, 675, 678
MGA	Televisions	<b>504, 575</b> , 505, 506, 542, 571, 573, 627, 652, 653, 654, 656, 660, 728
Mitsui	Televisions	769
Mitsubishi	Televisions	<b>504, 572</b> , 505, 542, 570, 571, 573, 597, 623, 627, 652, 653, 654, 656, 659, 660, 664, 665, 670, 671, 705, 728
Montgomery Ward	Televisions	<b>682</b> , 675
Motorola	Televisions	521, 605, 651
MTC	Televisions	505, 506, 516, 523, 573, 627, 652, 653, 654, 659, 664, 667, 672, 680
Multitech	Televisions	657
NAD	Televisions	502, 617, 627, 631, 635, 637, 654
National	Televisions	509
NEC	Televisions	<b>505, 660</b> , 506, 507, 517, 523, 573, 627, 651, 652, 653, 654, 664, 665, 679, 681, 731, 732
Nikkai	Televisions	612
Nikko	Televisions	654, 672, 727
Olevia	Televisions	<b>506</b> , 127
Onwa	Televisions	541, 657, 661
Optimus	Televisions	637
Optonica	Televisions	521, 605, 607
Orion	Televisions	<b>694</b> , 720
Osaki	Televisions	612
Panasonic	Televisions	<b>512, 689, 508</b> , 234, 247, 509, 510, 566, 644, 651, 662, 663, 668, 672, 673, 676, 685, 698, 700, 716, 734, 747, 761, 765

Philco	Televisions	505, 506, 525, 536, 568, 573, 610, 651, 652, 653, 654, 655, 656, 659, 660, 664, 665, 666, 669, 671, 672, 674, 677, 723, 724, 729
Philips	Televisions	<b>566, 565, 556, 688</b> , 525, 551, 652, 655, 656, 671, 690, 723, 724, 729, 770
Pioneer	Televisions	<b>502, 520</b> , 548, 576, 636, 637, 648, 652, 654, 663, 665, 681, 708
Polaroid	Televisions	<b>627, 659</b> , 688
Portland	Televisions	505, 526, 573, 652, 654, 658, 659, 664, 665, 670, 727
Price Club	Televisions	680
Prism	Televisions	676
Proscan	Televisions	<b>503</b> , 645, 646, 650, 668, 691, 725, 742
Proton	Televisions	513, 519, 526, 536, 585, 627, 652, 654, 655, 659, 660, 665, 666, 668, 670, 678
Quasar	Televisions	<b>700, 508, 512, 673, 614, 663</b> , 509, 651, 676, 698, 747
Radio Shack/Realistic	Televisions	<b>607</b> , 526, 541, 590, 612, 645, 650, 652, 654, 655, 657, 658, 661, 662, 663, 668, 670, 683, 698, 730
RCA	Televisions	<b>503, 742</b> , 505, 548, 586, 630, 633, 634, 636, 641, 645, 646, 648, 650, 651, 652, 653, 654, 656, 661, 663, 665, 667, 668, 670, 681, 691, 698, 701, 708, 715, 716, 725, 749
Realistic	Televisions	590, 645
Runco	Televisions	501
Sampo	Televisions	506, 519, 652, 654, 658, 663, 664, 665, 698, 730, 746
Samsung	Televisions	<b>516, 738</b> , 505, 506, 523, 526, 566, 573, 612, 627, 647, 652, 653, 654, 655, 656, 658, 659, 664, 665, 667, 669, 670, 679, 680, 704, 717, 730, 738, 755
Sansui	Televisions	<b>227, 754, 721</b>
Sanyo	Televisions	<b>590, 683, 589</b> , 542, 652
SBR	Televisions	566
Schneider	Televisions	566
Scott	Televisions	<b>541</b> , 526, 534, 537, 600, 652, 654, 655, 657, 661, 662, 665, 670, 677, 682, 696, 701
Sears	Televisions	<b>595</b> , 523, 534, 542, 563, 590, 601, 604, 617, 627, 631, 635, 645, 646, 650, 652, 654, 656, 659, 661, 668, 670, 682, 683, 688, 691, 703, 725, 726
Sharp	Televisions	<b>628, 605, 608, 740</b> , 521, 526, 585, 607, 629, 652, 654, 655, 658, 669, 670, 674, 679, 739, 741
Signature	Televisions	<b>715</b> , 675
Solavox	Televisions	612
Sony	Televisions	<b>500, 514</b> , 578, 640, 670, 690, 758
Soundesign	Televisions	525, 536, 541, 627, 652, 654, 657, 659, 661, 665, 666, 682
Starlite	Televisions	657
Supra	Televisions	523
Sylvania	Televisions	<b>632, 569, 556</b> , 506, 525, 536, 566, 568, 573, 600, 610, 652, 654, 656, 659, 660, 664, 665, 666, 671, 672, 674, 677, 723, 724, 729, 733, 756, 764
Symphonic	Televisions	<b>632</b> , 657, 662, 677, 692, 694
Tandy	Televisions	521, 605
Tatung	Televisions	509, 651, 663, 698
Technics	Televisions	508, 673, 676
Techwood	Televisions	523, 573, 652, 654, 660, 676
Teknika	Televisions	504, 505, 512, 516, 523, 524, 525, 526, 534, 536, 541, 573, 644, 652, 653, 654, 655, 657, 658, 661, 662, 664, 665, 666, 670, 672, 675, 680, 681, 682, 685, 726, 727
Telefunken	Televisions	679
Toshiba	Televisions	<b>617, 615, 631</b> , 516, 590, 635, 667, 678, 680, 683, 688, 750
Totevision	Televisions	526, 658, 668
Ultra	Televisions	672
Universal	Televisions	543, 690
Vector Research	Televisions	506
Video Concepts	Televisions	570, 661
Viewsonic	Televisions	566, 760
Vizio	Televisions	505, 627, 775, 758, 756, 885, 864.
Wards	Televisions	536, 573, 607, 645, 650, 652, 653, 654, 656, 659, 664, 665, 666, 667, 668, 669, 674, 675, 677, 678, 682, 690, 715, 723, 724, 729

White Westinghouse	Televisions	<b>719</b> , 500, 630, 631, 659, 664, 670, 672, 674
Yamaha	Televisions	505, 506, 573, 652, 653, 654, 656, 664, 666, 672, 679
Zenith	Televisions	<b>501</b> , 520, 639, 652, 672, 675, 693, 747

Click [HERE](#) to return to the top.

Remote VCR Codes		
BRAND	CATEGORY	CODE
Aiwa	VCRs	588, 622, 623
Akai	VCRs	513, 514, 515, 516, 517, 518, 520, 568, 682
Alba	VCRs	546
Amstrad	VCRs	588
ASA	VCRs	556
Audiovox	VCRs	676
Bell & Howell	VCRs	581
Broksonic	VCRs	559, 748
Bush	VCRs	589
Calix	VCRs	676
Canon	VCRs	554, 678, 679
Capehart	VCRs	546
CCE	VCRs	681
Citizen	VCRs	534, 591, 592, 594, 675, 676, 677, 684
Colortyme	VCRs	592
Craig	VCRs	591, 608, 658, 675, 676, 681, 685, 687, 688
Curtis Mathes	VCRs	554, 592, 594, 605, 607, 675, 677, 678, 679, 683, 684
Daewoo	VCRs	506, 534, 546, 547, 559, 588, 684
Daytron	VCRs	546
Denon	VCRs	686
Dimensia	VCRs	607
Dumont	VCRs	549
Electrohome	VCRs	512, 676, 687
Emerson	VCRs	505, 506, 508, 509, 511, 512, 534, 559, 568, 588, 590, 618, 676, 678, 684, 687
Finlandia	VCRs	549
Finlux	VCRs	549, 556, 588
Fisher	VCRs	548, 549, 581, 584, 588, 608, 610, 684, 688
Fuji	VCRs	678
Funai	VCRs	588
Garrard	VCRs	588
General Electric (GE)	VCRs	550, 551, 552, 554, 572, 591, 605, 607, 675, 678, 679
Go Video	VCRs	557, 558, 620, 685
Goldstar	VCRs	592, 594, 676, 687, 747
Goodmans	VCRs	585, 589
Gradiente	VCRs	588, 687
Granada	VCRs	549, 581
Grundig	VCRs	556
Harman/Kardon	VCRs	568, 592
Harwood	VCRs	681
Hinari	VCRs	589
Hitachi	VCRs	536, 538, 539, 540, 588, 595, 597, 680, 682, 686
ITT	VCRs	518
JC Penney	VCRs	554, 581, 591, 592, 594, 595, 600, 674, 675, 676, 678, 679, 680, 681, 685, 686, 687
Jensen	VCRs	595, 680, 682
JVC	VCRs	561, 562, 563, 581, 592, 594, 600, 674, 682, 686
Kenwood	VCRs	562, 581, 592, 594, 600, 674, 677, 682, 683
KLH	VCRs	681
Kodak	VCRs	676, 678
Lloyds	VCRs	683, 688
Logik	VCRs	589, 681, 685

Luxor	VCRs	518
LXI	VCRs	676
Magnasonic	VCRs	685, 687
Magnavox	VCRs	527, 533, 554, 556, 678, 679, 684, 685
Marantz	VCRs	554, 556, 581, 585, 592, 594, 600, 602, 674, 673, 677, 678, 683
Matsushita	VCRs	678
Memorex	VCRs	507, 533, 549, 554, 566, 581, 585, 588, 608, 675, 676, 678, 686, 687, 688
MGA	VCRs	512, 567, 568
Minolta	VCRs	595, 680, 686
Mitsubishi	VCRs	512, 562, 567, 568, 570, 571, 595, 680, 687
Motorola	VCRs	678
MTC	VCRs	544, 588, 675, 685
Multitech	VCRs	579, 588, 675, 677, 681
NAD	VCRs	573
NEC	VCRs	562, 581, 592, 594, 600, 602, 674, 677, 682, 683
Nikko	VCRs	676
Noblex	VCRs	675
Olympus	VCRs	678
Optimus	VCRs	676, 687
Optonica	VCRs	585
Orion	VCRs	506, 684, 687
Panasonic	VCRs	523, 554, 598, 614, 628, 633, 678, 679, 684, 685, 688, 747
Pentax	VCRs	592, 595, 677, 680, 683, 686
Pentax Research	VCRs	594
Perdio	VCRs	588
Philco	VCRs	554, 678, 679, 686
Philips	VCRs	554, 556, 585, 678, 684
Pioneer	VCRs	562, 573, 574, 575, 576, 600, 674, 680
Portland	VCRs	546, 677
Proscan	VCRs	605, 607
Proton	VCRs	685
Quasar	VCRs	554, 604, 614, 678, 679, 747
Radio Shack/Realistic	VCRs	512, 534, 549, 554, 581, 584, 585, 588, 607, 608, 610, 675, 676, 678, 679, 687, 688
Radix	VCRs	676
RCA	VCRs	518, 525, 527, 528, 591, 595, 605, 607, 615, 631, 649, 675, 678, 680, 686
Ricoh	VCRs	502
Runco	VCRs	533
Saisho	VCRs	506
Salora	VCRs	567, 581
Samsung	VCRs	738, 515, 517, 534, 579, 591, 675, 755
Sansui	VCRs	544, 562, 600, 674, 682, 685
Sanyo	VCRs	549, 581, 582, 583, 608, 675, 688
SBR	VCRs	556
Schneider	VCRs	589
Scott	VCRs	508, 534, 559, 590, 684, 687
Sears	VCRs	548, 549, 581, 584, 595, 608, 610, 676, 678, 680, 683, 684, 686, 687, 688
Sentra	VCRs	546
Sharp	VCRs	512, 585, 607, 625
Shintom	VCRs	589, 595, 681, 685
Singer	VCRs	678, 681, 685
Sony	VCRs	500, 501, 502, 504
STS	VCRs	678
Sylvania	VCRs	554, 556, 567, 588, 678, 679, 756
Symphonic	VCRs	588, 594, 683, 688
Tandy	VCRs	581, 588
Tashiko	VCRs	588, 676
Tatung	VCRs	594, 682

Teac	VCRs	588, 594, 682
Technics	VCRs	554, 633, 678
Teknika	VCRs	554, 588, 676, 678, 687
Toshiba	VCRs	534, 535, 567, 584, 590, 680, 684, 688
Totevision	VCRs	591, 675, 676, 687
Unitech	VCRs	675
Vector Research	VCRs	534, 592, 600, 674, 677, 683
Video Concepts	VCRs	534, 568, 592, 600, 674, 677, 683
Wards	VCRs	534, 588, 595, 608, 675, 676, 678, 680, 681, 684, 687, 688
XR-1000	VCRs	588, 678, 681
Yamaha	VCRs	581, 592, 594, 600, 674, 682, 683
Zenith	VCRs	500, 501, 533, 747

Click [HERE](#) to return to the top.

Stereo Amplifier Codes		
BRAND	CATEGORY	CODE
Aiwa	Amplifiers	636, 641, 656, 687, 718, 720, 724, 775, 726, 774
Boss	Amplifiers	761
Carver	Amplifiers	653
Citizen	Amplifiers	709
Curtis Mathes	Amplifiers	734
Denon	Amplifiers	647, 674
Fisher	Amplifiers	653, 741
GE	Amplifiers	711
Goldstar	Amplifiers	677, 690
Harmon/Kardon	Amplifiers	640, 672, 751
Hitachi	Amplifiers	717, 754
JBL	Amplifiers	640
JVC	Amplifiers	637, 683, 703, 725
Kenwood	Amplifiers	649, 676, 691, 726, 728, 745
Luxman	Amplifiers	752
Magnavox	Amplifiers	654, 705, 740
Marantz	Amplifiers	651, 740, 742, 743
NAD	Amplifiers	739
Nakamichi	Amplifiers	671, 748, 750
NEC	Amplifiers	716, 739
Onkyo	Amplifiers	642, 660, 662, 678
Optimus	Amplifiers	648, 664, 734, 744, 749
Panasonic	Amplifiers	643, 644, 652, 742, 746
Pioneer	Amplifiers	658, 667, 668, 679, 702, 734
Proton	Amplifiers	654, 705
Quasar	Amplifiers	652, 742, 746
Radio Shack	Amplifiers	744
RCA	Amplifiers	635, 638, 704, 727
Sansui	Amplifiers	753
Sanyo	Amplifiers	741
Sharp	Amplifiers	712, 713, 714, 715, 749
Sherwood	Amplifiers	646, 670, 736, 738, 744
Sony	Amplifiers	639, 645, 650, 687, 728, 729, 730
Soundmatters	Amplifiers	763
Teac	Amplifiers	684, 737
Technics	Amplifiers	643, 644, 652, 742, 746
Toshiba	Amplifiers	710
Yamaha	Amplifiers	663, 730, 731, 732, 733, 745, 747

Click [HERE](#) to return to the top.

Combo Codes		
BRAND	COMBO	CODE
Broksonic	TV/VCR	748
Goldstar	TV/VCR	747

Panasonic	TV/VCR	747
Quasar	TV/VCR	747
Samsung	TV/VCR	738, 755
Sylvania	TV/VCR	756
Zenith	TV/VCR	747
Aiwa	TV/DVD	751
Broksonic	TV/DVD	752
Konka	TV/DVD	753
Panasonic	TV/DVD	734
RCA	TV/DVD	749
Sansui	TV/DVD	754
Toshiba	TV/DVD	750
Go Video	DVD/VCR	692, 693
JVC	DVD/VCR	689
RCA	DVD/VCR	690
Samsung	DVD/VCR	738, 667, 691

#### DVD Codes

BRAND	CATEGORY	CODE
Aiwa	DVD	634, 694, 751
Alpine	DVD	653
Apex	DVD	654, 655, 743, 744, 757
Boss	DVD	758
Broksonic	DVD	656, 752
Clarion	DVD	696
Classic	DVD	695
Daewoo	DVD	657
Denon	DVD	697, 698, 699, 700
Emerson	DVD	658, 701
Fisher	DVD	659
Funai	DVD	658
GE	DVD	702, 703
Go Video	DVD	692, 693
GPX	DVD	704
Hitachi	DVD	632, 635, 660, 705, 706, 707
JVC	DVD	636, 689, 708, 711
Kenwood	DVD	761
Konka	DVD	637, 638, 753
Koss	DVD	745
Lasonic	DVD	762
Magnavox	DVD	626, 661
Memorex	DVD	709
Mintek	DVD	710
Mitsubishi	DVD	629
NAD	DVD	701
Nakamichi	DVD	763
Norcent	DVD	762, 712
Onkyo	DVD	713
Oritron	DVD	723
Panasonic	DVD	639, 662, 663, 714, 715, 716, 717, 734, 765
Philips	DVD	640, 641, 766
Pioneer	DVD	665, 718, 719
Proscan	DVD	720
Qwestar	DVD	721, 723
RCA	DVD	627, 650, 666, 690, 742, 749
Sampo	DVD	724

Samsung	DVD	738, 651, 652, 667, 668, 691, 740, 741
Sansui	DVD	725, 754
Sanyo	DVD	643, 726
Sharp	DVD	669, 727, 746
Sherwood	DVD	728
Sony	DVD	617, 644, 645, 670, 671, 729, 730, 731
Sylvania	DVD	658, 764
Teac	DVD	732
Technics	DVD	733
Techwood	DVD	664
Toshiba	DVD	616, 646, 647, 672, 735, 736, 750
Yamaha	DVD	737, 738, 739
Zenith	DVD	648, 673

Click [HERE](#) to return to the top.

Monday October 29 2007 ©2006 EchoStar Satellite L.L.C. All rights reserved.